


UNDERWOOD TYPEWRITER



- | | | |
|-------------------------------|--|---------------------------------|
| 1. Line Space Adjusting Lever | 11. Cylinder Knobs | 20. Shift Lock |
| 2. Lateral Paper Guide | 12. Carriage Release Levers (Right and Left) | 21. Shift Key (Right and Left) |
| 3. Cylinder | 13. Thumb Brace Carriage Control | 22. Space Bar |
| 4. Paper Holder Bail | 14. Left Margin Release Latch | 23. Tabulator Stop Set Key |
| 5. Aligning Scales | 15. Front Scale | 24. Tabulator Bar |
| 6. Paper Centring Scales | 16. Marginal Stops | 25. Tabulator Stop Clear Key |
| 7. Card Holders | 17. Front Plate | 26. Back-spacer |
| 8. Paper Rest | 18. Ribbon Indicator | 27. Touch Tuning |
| 9. Writing Position Pointer | 19. Margin Release Key | 28. Line Space Lever |
| 10. Paper Release Lever | | 29. Variable Line Spacer Button |
| | | 30. Automatic Line Finder |