


REMINGTON TYPEWRITER



- | | | |
|--|---|-------------------------------------|
| 1. Space Bar | 11. Snap-off Top Plate | 20. Card Holder
(Right and Left) |
| 2. Shift Keys
(Left and Right) | 12. Platen Knob
(Right and Left) | 21. Aligning Scale |
| 3. Shift Lock
(Left and Right) | 13. Variable Line Spacer | 22. Type Guide |
| 4. Back Space Key | 14. Line Space Regulator | 23. Paper Bail |
| 5. Keyboard Margin Control
(Left and Right) | 15. Carriage Release Lever
(Right and Left) | 24. Paper Release Lever |
| 6. Tabulator Clear Key | 16. Ratchet Detent or Release Lever | 25. Paper Bail Release |
| 7. Tabulator Bar | 17. Removable Platen Brackets
(Right and Left) | 26. Carriage Scale |
| 8. Ribbon Reverse | 18. Adjustable Paper Side Guide | 27. Ribbon Indicator |
| 9. Key Release Lever | 19. Paper Centring Scale | 28. Personal Touch Regulator |
| 10. Carriage Return and Line Space Lever | | 29. Tabulator Set Key |
| | | 30. Margin Release Key |